


User Manual

This product is for indoor use only **G200S**



TRUE HEPA AIR PURIFIER

ENGLISH

Thank you for purchasing from Ganiza. If you have any questions or need further assistance, please contact us at **service@ganiza.com**

CONTENTS

IMPORTANT SAFETY INSTRUCTIONS 0
WHAT'S INCLUDED 02
KNOW YOUR AIR PURIFIER 02
Product Overview 02
Control Panel 03
Filtation System 03
SPECIFICATIONS 04
GET STARTED OS
USE YOUR AIR PURIFIER 06
Turn On/Off 06
Fan Speed Adjustment 06
Sleep Mode 07
Filter Replacement 0
Child Safety Lock 07
Auto Mode 08
Timer 08
MAINTENANCE AND CARE 09
Clean the Air Purifier 09
Replace the HEPA&Activated Carbon Filter 11
Storage11
TROUBLESHOOTING GUIDE 11

IMPORTANT SAFETY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

Power Supply

- * This appliance has a polarized plug(one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
- * To Reduce The Risk Of Fire Or Electric Shock, Do Not Use This Fans With Any Solid-State Speed Control Device.
- * Please do not over bend or twist the power cord,as this may damage it.
- * Do not use any inapplicable AC outlets.

Warning

- * Users should only operate the air purifier once they have understood all the following important safety instructions. Users who have a disability and need assistance are responsible for seeking support and ensuring their own safety in line with the instructions given in this manual.
- * Children should be supervised to ensure that they do not play with the appliance.

Moving

- * Turn off and unplug the air purifier before moving it.
- * Firmly grab the groove of the air purifier to avoid excessive vibration or injury due to falling.

Installation

* Keep a distance of at least 38cm/15inches between the air inlets and walls or other objects.

Where in Use

- * Please immediately stop using the air purifier if overheats,makes unusual sounds, gives off unpleasant odors, or its fan rotates irregularly.
- * Do not put your fingers or other objects into the air inlet, air outlet, or filter compartment.
- * Keep hair or cloth away form the air purifier to avoid them getting into and blocking the inlet/outlet.
- * Please do not sit on, lean on, or tilt the air purifier.
- * Please ventilate when using the air purifier together with any combustion equipment, e.g., fireplace or barbecur oven, etc., to keep you safe from carbon monoxide.
- * Always place the air purifier out of the reach of patients, children, or pets.
- * Please keep your air purifier aways from any heat sources, such as stove, oven, electric heater, etc.

Tips for Essential Oils

- * Do not add any essential oils to the air purifier or the filter. If you are doing so, the HEPA&Activated Carbon Filter will be damaged and eventually release an unpleas ant odor.
- * Do not use any essential oil diffuser near the air purifier.

Ganiza will accept no liability or responsibility for fires or electrical shocks caused by improper operation or not adhering to the above safety instructions.

WHAT'S INCLUDED



Air purifier x1



HEPA&Activated Carbon Filrer (inside the Filter compartment) x1




User Manua**l** x1





Quick Guide x1

KNOW YOUR AIR PURIFIER

Product Overview







Control Panel



Power On/Off

 \prime * Turn on/off the air purifier.



Fan Speed

* Cycle through 3 fan speed options: Sleep 1 (low), 2 (medium), and 3 (high).



Sleep Mode

* Enable or disable sleep mode.



Filter Reaplcement Indicator

 $^{\prime}$ * Flashing when the HEPA&Activated Carbon Filter should be replaced.



Child Safety Lock

* Prevent the current settings from being changed accidentally by children or pets.



Auto Mode

* Automatically adjust wind speed to purify air according to air quality.




Time

* Set the time duration to automatically power off the air purifier.

Filtration System

The air purifier's filtration system consists of the Pre-filters and the HEPA&Activated Carbon Filter.



1. Pre-filters

> The pre-filters can filter large particles such as dust, lint, fibers, hair, and pet hair.

2. Ture HEPA&Activated Carbon Filter

HEPA

- * Filter out particles 0.3 microns in diameter from at least 99.97% of the air.
- > The HEPA can filter samII particles such as smoke, dust, mold spores, bacteria.
- > Viruses, and allergens such as pollen, pet dander, and dust mites.

3. Activated Carbon Filter

- > This layer is to deal with odors or smoke.
- > This layer can also filter the organic compound such as formaldehyde, ammonia, hydrogen sulfide, and volatile organic compound.

· Temperature Conditions for Using the Filter

* Excessive moisture may damage the filter. The air purifier should be used in an area with a humidity level below 85% RH. If you use the air purifier in excessively humid areas, the surface of the filter part will become moldy.

SPECIFICATIONS

Voltage Input	AC120V,60Hz
Rated Power	45W
Standby Power	<1W
Dimension	243*253*473mm/9.56*9.96*18.62inches
Net Weight	4kg/141.090Z

GET STARTED


Step 1:

Flip over the air purifier and open the filter cover.




Step 2:

Remove the protective plastic bag from the HEPA&Activalted Carbon Filter, and reinstall the filter into the housing.




Step 3:

Close the filter cover, and turn over the air purifier to get it ready for use.








USE YOUR AIR PURIFIER

® Turn On/Off

- (1) After connecting the air purifier to power, press (6) to turn it on, and it will start purifying the air with the default fan speed.
- 2) Press (a) again to turn off the air purifier.

Fan Speed Adjustment

- ① There are three speed options for this air purifier, which include Speed1 (low), 2 (medium), and 3 (high).
- ② Press ② to cycle through three fan speed options, and the corresponding fan speed indicator will light up.



Tips:

- The fan speed indicators are not the buttons to adjust the speed.
- The fan speed option of 3 is the highest level that can purify the air quickly, but it will make louder sounds.
- To effectively purify the air, please close your windows and doors while the air purifier is working. But do ventilate if you are using some combustion equipment, e.g, fireplace or barbecue oven; this is to keep you safe from carbon monoxide.

Sleep Mode

- ① When the air purifier is working, press ② to enter the ③ . All the lights, including the indicators and air quality senor light, will be off, and the air purifier will continue to work with the lowest fan speed.
- 2) Press (2) again to exit the (3), and the air purifier will return to the I (low).



Tips:

In sleep mode, timer adjustment are available. The corresponding indicator will light up for 1s when setting and then turn off.

Filter Replacement


- ① When the filter is at the end of its service life, the indicator has been flashing to remind you to replace the filter with a new one.
- ② Reset the service time of the new filter after replacement. Please long press **()** for 5s until the indicator normally on.



(a) Child Safety Lock

This function is to prevent the current settings from being changed accidentally by children or pets.

- ① Long press @ for 3s to enable the Child Safety Lock, and the button will light up in white. All the other buttons will be deactivated.
- ② Long press @ for 3s again to exit this mode, and all the other buttons will be activated.



@ Auto Mode

This indicator uses an automatic sensor to display the air quality. This sensor uses an infrared light to detect airborne particles.

- (1) The air purifier will take 10 seconds to detect the air quality each time it is turned on. During this time, the color of the air quality indicator will be green. After 10 seconds, the color of the air quality indicator will change based on the detected air quality.
- 2) Press @ again to turn off the Auto Mode.



Air Quality Indicator Chart				
Indicator Color	Air Quality	Fan Speed		
Green	Good	Low		
Orange	Moderate	Medium		
Red	Bad	High		

Tip:

Auto Mode adjusts the fan speed automatically based on air quality. For example, if the air quality is bad, the fan will be set to high speed.

Timer

Four timer options are available, including 1H, 2H, 4H, and 8H.

- ① Press ③ once at a time to select a timer. The corresponding indicator will light up.
- ② Press ③ the fifth time or long press it for 1.5s to disable the timer function. The timer indicator will be off.



Tips:

The timer indicators are not the buttons to change the timer duration. The air purifier will automatically power off once the timer ends.


MAINTENANCE AND CARE

Filter Frequency	Cleaning Frequency	Replacing
Pre-filter	Once or twice per month	/
HEPA&Deodorization Filter	/	3-6 months

Clean the Air Purifier

Step 1:

Unplug the air purifier before cleaning.



Step 2:

Wipe clean the air purifier's housing with a soft, dry cloth or brush. If necessary, wipe clean the housing with a damp cloth and dry it immediately.



Step 3:

Turn over the air purifier, open the filter cover, then take out HEPA&Activated Carbon Filter



Step 5:

Vacuum the pre-filters, or wipe them with a damp cloth and make them dry completely.



Step 4:

Vacuum inside the filter compartment.



Step 6:

Reinstall the HEPA&Activated Carbon Filter into the air purifier, then close the cover.



- · If the pre-filters are not cleaned sufficiently, gently wash them under the water with a soft brush. DO NOT reinstall them into the air purifier before they dry completely.
- Do not clean any parts with abrasive chemicals or flammable agents.
- · Do not wash the HEPA&Activated Carbon Filter, as this may damage it.

Replace the HEPA&Actirated Carbou Filter

- > Generally, the HEPA&Activated Carbon Filter should be replaced every 3-6 months. If the air purifier is frequently used in an environment with relatively high pollution, you will need to replace the HEPA&Activated Carbon Filter more often.
- > The indicator (a) will flash in white to remind you to replace the HEPA&Activated Carbon Filter.
- > You may need to replace the HEPA&Activated Carbon Filter if you notice:
 - * increased noise when the air purifier is turned on;
 - * decreased airflow from the air outlet:
 - * unpleasant odor from the air outlet;
 - * a visibly clogged and black filter.

Tips:

- To maintain the air purifier's optimal performance, please use the original filter made by Ganiza. Please contact us to get the purchase link.
- Do not forget to reset the service time of the filter after replacing it.

Storage

If the air purifier is not used for an extended period of time, please cover the air purifier and filters with protective plastic bags, then store them in a dry place.







TROUBLESHOOTING GUIDE

If you need any further assistance, please feel free to contact us. To maintain the air purifier's optimal performance, please regularly clean the air purifier and remove objects that block the air inlet.

Q1. The air purifier produces an unusual noise after it's turned on.

- * Make sure the HEPA&Activated Carbon Filter is removed from the plastic bag and properly installed.
- * Make sure the air purifier is working on a hard, flat, and even surface.
- * The air purifier may be damaged, or there may have foreign objects inside.

Please stop using the air purifier and contact us. Do not attempt to repair the air purifier yourself.

Q2. An unpleasant odor is coming from the air purifier.

- * Clean the pre-filters, or replace the HEPA&Activated Carbon Filter if necessary.
- * Stop using the air purifier and contact us.

Q3. The air purifier can't be turned on or stops working.

- * Check if the air purifier is plugged in.
- * Check if the power cord is damaged. If yes, stop using the air purifier and contact us.
- * Try to plug the air purifier into a different outlet.
- * The air purifier is malfunctioning. Please contact us.

Q4. The air quality is still poor after using the air purifier.

- * Make sure the HEPA&Activated Carbon Filter is removed from the plastic bag and properly installed.
- * Tap (2) to adjust the fan speed to a higher level.
- * Please make sure the air inlet and air outlet of the air purifier are not blocked by any objects. Leave 38 cm/15 inches of clearance on all sides of the air purifier.
- * Close the doors and windows while using the air purifier.
- * Please check if the pre-filters are clogged by some large particles, such as hair or lint. If yes, please clean the pre-filters.
- * Replace the HEPA&Activated Carbon Filter.

Q5. The Filter Replacement Indicator is still on after I replace the HEPA&Activated Carbon Filter with a new one.

* After replacing the filter, please long press (a) for 5s until the indicator flashes 3 times to reset the service time.

Q6. The Filter Replacement Indicator is still off after I use the air purifier for 6 months, or it flashes less than 3 months after use.

* The indicator is to remind you to check the HEPA&Activated Carbon Filter. It flashes depending on the use frequency of the air purifier and the air quality. If you don't use your air purifier often, it will take longer to flash. If you use it frequently, it will take shorter to flash.

Q7. The touch panel isn't working.

- * Ensure the Child Safety Lock is turned off.
- * The air purifier is malfunctioning. Please contact us.

Q8. Where to buy HEPA&Carbon Activated Filters?

* Please contact us to get the purchase link, Thanks.

Q9. Display shows Error Code "E1".

When the machine is in operation, opening the screen cover, the button is invalid, the indicator light flashes, and the display screen is in "E1"state. After closing, it will return to normal

HOMAX LINK LIMITED

Flat F,12/F, Golden Dragon Industrial Centre Block 1, 152-160 Tai Lin Pai Rd, Kwai Fong service@ganiza.com

Made In China

CUSTOMER SUPPORT

service@ganiza.com