
Linkind


User Manual

16 LED Solar Landscape Spotlights

Model:OC-GL-034B



SPECIFICATION



LED	16LED
IP Rating	IP65
Working temperature	-10-40°C
Housing material	ABS
Induction mode	Light control
Illumination angle	90°

INTRODUCTION

The solar landscape spotlights can automatically detect the changes in the brightness of the external environment. When the brightness is low enough, it will automatically switch from energy-saving mode to lighting mode without motion detection (Auto on at night / Auto off at sunrise).





PACKAGE CONTENTS

- A 2 x Solar Landscape Spotlights
- B 2 × Plastic Anchor
- C 2 x Plastic rod
- D 2 x turn-knob
- F 4 x Gecko screw
- 4 x Screws
- G 1x User Manual











A 2PCS

B 2PCS C 2PCS



*Note: If 4 Pack, content A-F will double

INSTALLATION

Press the back button and select a desired mode. Then choose a place that can get enough sunshine to install the light, the more it gets sunshine, the longer it can illuminate.


Method 1: Ground Inserted

- ①Connect the ground stake with the light. Then, adjust the angle of lamp holder and tighten the knob.
- ②Insert the whole light into the ground vertically.




Method 2: Wall Mounted

- ①Punch two holes on the wall with a drill bit and insert the attached wall plugs into holes. Then, twist the screws through the screw holes of holder into the wall plugs.
- ②Adjust the angle, then tighten the holder and the light through the knob screw. Adjustable Angle: horizontal 180°, vertical 90 °



OPEARTION GUIDE

The default mode of the product is OFF mode. Press the back button to adjust modes when using the light.



3 LIGHTING MODES

LOW Light Mode

Press the power button for once, the landscape light will charge but not light up in the day, and it will automatically light up in darkness or at night. (Max working time:12Hrs consecutive lighting)

HIGH Light Mode

On the basis of LOW Light Mode, press the power button again, the landscape light will charge but not light up in the day, and it will automatically light up in darkness or at night. (Max working time:6Hrs consecutive lighting)

OFF:

On the basis of HIGH Light Mode, press the power button again, the landscape light will power off.

WARM TIPS

LOW Light Mode

- 1.It is recommended to turn off the light and charge it under direct sunlight for 1-2 days before the first use. Make sure the product has enough power.
- During the installation, please make sure the landscape light is installed under direct sunlight where there is no shade or eave to shelter the solar panel. Otherwise, the lighting time will be shorter.
- 3. Whether the solar landscaping spotlights can produce the best lighting effect or not depends on sunlight intensity, geographical location, weather conditions, seasons and other conditions.

Linkind

Thank you for choosing our products. The product is under warranty for 2 years beginning on the date of purchase. For any issues concerning the quality during the period, please feel free to contact us.

- © 1-855-999-6677(24x7)
- @service@linkind.com
- ♠ http://www.linkind.com
- ⊕
 ⊚
 @ linkintec
- (a) Why not share your stories to help other buyers?

